

Content

	Prologue	9
1	What you will need	12
2	Tutorial	17
2.1	Concept	17
2.2	Hardware	17
2.3	Software	22
2.4	Simulation	29
2.5	Downloading	31
2.6	Operational	32
3	Basic	33
3.1	LCD display	33
3.2	Running light	39
3.3	Secret doorbell	45
3.4	Serial communication	51
3.4.1	RS232	51
3.4.2	USB	58
3.5	Analog to Digital Conversion	62
3.6	Dark activated switch	66
3.7	Youth deterrent	70
3.8	Sound activated switch	77
3.9	Air to fuel ratio	80
3.10	Digital clock	87
3.11	Debugging	91
3.11.1	Simulation	93
3.11.2	Serial connection	94
3.12	Bootloader	96
4	Advanced	100
4.1	Vref+	100
4.2	Record short sounds	105
4.3	Cricket	111
4.3.1	High quality version	111
4.3.2	Low cost version	116
4.4	Custom Characters	119
4.5	Animation	123

4.6	Random	124
4.7	A fan on PWM	128
4.8	Persistence of vision	135
4.9	Flash memory	139
4.10	USART connection	144
4.11	GPS tracking	149
4.12	Use PPP to access EEPROM	155
4.13	Poetry box	159
4.14	Voice command	163
5	Sensors	169
5.1	Infrared object detection	169
5.2	Photometer	172
5.3	Ultrasonic range finder	178
5.4	Digital thermometer	184
5.5	Data sampling the fridge	189
5.6	Heat loss in a residential building	197
5.7	Capture sound frequency	202
5.8	Tow away alarm	212
6	Cell phone	217
6.1	Send a text message	217
6.2	Receive a text message	221
6.3	Remote control	225
7	CAN bus	232
7.1	Remote LEDs	232
7.2	Monitor	240
8	Internet	248
8.1	Ping (Are you there?)	248
8.2	Webserver	258
8.3	Send an alarm e-mail	265
8.4	UDP remote control	276
9	Design your own E-block	282
9.1	Analog test signal	282
9.2	Microphone pre-amplifier	284
10	Migration between PIC, AVR and ARM	288
10.1	Software	288
10.2	Hardware	289
10.3	Example	293

11	Going into production	296
11.1	Youth deterrent (continued)	296
12	Appendix	302
12.1	ASCII table	302
12.2	Visual Basic communications	303
12.3	Tips and tricks	305
12.4	Microcontroller Mathematics	314
12.5	E-block connections	320
	Index	327